

Brett Sims Switch Grip

SKU: NWBS-SGxx

Required Tools:

- 7/32" Hex Key (Allen Wrench)



Part Number	Part Description	Quantity
CUSTOM	Switch Grip (body)	1
CUSTOM	Bearing with Bracket	2
91255A632	3/8" x 2" Hex Bolt	4
1133622	3/8" Lock Washer	4
1133008	3/8" Flat Washer	4

Need help?

Call 1-800-932-3339 or
Email info@gymsupply.com

Step 1:

Remove the $\frac{3}{8}$ " x 2" Hex Bolt, $\frac{3}{8}$ " Flat Washer, and $\frac{3}{8}$ " Lock Washer from each Bearing with Bracket.



Step 2:

Align the first **Bearing with Bracket** with the pre-drilled holes on the **Switch Grip Body**. Thread the **Hex Bolt**, **Lock Washer**, and **Flat Washer** through the bottom of the **Switch Grip Body** into the **Bearing with Bracket**. Tighten securely using a $\frac{7}{32}$ " **Hex Key**.

Step 3:

Repeat **Steps 1 and 2** to attach the second **Bearing with Bracket**, making sure it faces opposite the first **Bearing**.

IMPORTANT:

The Switch Grip is easy to adjust for various uses! Start by using a $\frac{7}{32}$ " **Hex Key** to remove the **Hex Bolt**, **Flat Washer**, and **Lock Washer** from the **Bearing with Bracket**. To change the board's rotation direction, move the Bearings to the opposite set of holes. For lefty or righty configurations, rotate the board to your desired side before reinstalling the Bearings.

